INTRODUCTION

This is an educational keychain game for you to look after your ***MEGA PETS*** to grow up healthily and happily. ***MEGA PETS*** need lots of attention daily including feeding, bathing, sleeping, cleaning, playing and discipline. Some of the activities must be carried out within a certain period of time. Don't be scare, you will be guided along the way with these instructions.

INSERTING THE BATTERIES

- To activate your ***MEGA PETS*** game first time, pull the plastic tab from back of unit.
- To insert batteries, remove the battery compartment cover at the back of the unit.
- Replace two 1.5V button cell, making sure to align "+" and "-" as shown.

CAUTION: Battery should be replaced by adult. Not suitable for children under 36 months, may contain small parts.

TO ENSURE PROPER FUNCTION

- Do not mix old and new batteries.
- Do not mix alkaline, standard or rechargeable batteries.
- Battery installation should be done by adult.
- Non-rechargeable batteries are not to recharged.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.

GAME START

When you turn the game on, you will see a puppy arrive in a trolley. A little ***MEGA PETS*** born and move around the screen. The first thing you should do is to set for your ***MEGA PETS*** to mark this joyous occasion!

SETTING THE CLOCK

- Press **MODE** to enter CLOCK MODE.

- Press and hold **ENTER** for 1.5 seconds to enter CLOCK SETTING MODE. 

- Set the current time press **LEFT** to adjust the hour, and **RIGHT** the minutes.
- Press **ENTER** to confirm the time and return to CLOCK MODE
- Press **Right** key to turn on/off the sound.
- Press MODE to enter back game mode.

HOW TO PLAY

- ***MEGA PETS*** require a certain kind of attention from you when the unit BEEP and the **ALERT** icon lights up.
- There are many ways for you to interact with your ***MEGA PETS***.
- Press **ENTER** to activate the activities

Use the **LEFT or RIGHT** key to select the activity you want, then press **ENTER**.

FEEDING

Press **LEFT** or **RIGHT** key to choose healthy food or pet treat. ***MEGA PETS*** need healthy food to grow, and treats to stay happy.



SLEEPING

Choose this icon to turn the light out when your pet wants to sleep, or to turn it back on when your pet is awake. Your pet will be happier if you turn out the light when it falls asleep.



PLAYING

To keep your pet healthy and happy, you should play with it oftentimes.

Direction Guessing game:
Press **LEFT** or **RIGHT** key to guess the direction of pet to face.

DOCTOR

Your ***MEGA PETS*** get sick sometimes just like a real pet. Choose this activity for medication while the sick mark showing on screen. If your pet is not sick, it will refuse to take medicine.

CLEANING

Sometimes your pet will leave droppings on the screen after eating or sleeping, choose BATHING to clear them away. If you want your ***MEGA PETS*** to stay healthy, don't leave droppings lying on the screen and don't let your pet walk around the dirties.

BODY CHECK

Choose this icon to check the conditions of ***MEGA PETS***. Press **LEFT** or **RIGHT** key to display screens showing your pets **AGE**, **WEIGHT**, **HUNGER**, **HAPPINESS**, **DISCIPLINE**. Filled gauge means very good while empty gauge means very bad.

DISCIPLINE

Your pet does not like to be disciplined but some discipline is required when ***MEGA PETS*** does not behave properly. Don't choose this activity too often, or your pet will become unhappy and unhealthy.

ALERT

Choose this icon to find out what happens to your ***MEGA PETS***. If no dump or sick mark is shown, it will show a happy face.

GAME OVER

The game is over when your pet dies. Your pet can die from bad health or old age.

RESTARTING THE GAME

If your pet dies or if you just wish to start over from the beginning, press **RESET** button at the back of the unit until the game resets.

MEGA PETS



© 1997 Timlex International Ltd.
All Rights Reserved.

PRINTED IN HONG KONG

86-G220-A001

WG-220 USER GUIDE